



EN BASIC FUNCTION table with columns for Windows and MAC, listing key functions like F1-F12, FN-F12, and FN-F14.

EN BASIC FUNCTION table with columns for Windows and MAC, listing key functions like F1-F12, FN-F12, and FN-F14.

EN PARIING BLUETOOTH section with a diagram of the keyboard and instructions for pairing via USB and wireless methods.

EN SPECS table listing model, keys amount (100 Keys), mounting type (Gasket), case material (ABS Plastic), and other specifications.

EN Hot-Swappable section with diagrams showing how to remove and replace keys using a key puller.

DE GRUNDFUNKTION table with columns for Windows and MAC, listing key functions in German.

DE GRUNDFUNKTION table with columns for Windows and MAC, listing key functions in German.

DE BLUETOOTH-KOPLUNG section with a diagram and instructions for pairing in German.

DE SPEZIALIEN table listing model, keys amount, and other specifications in German.

DE Hot-Swappable section with diagrams showing key replacement in German.

ES FUNCION BASICA table with columns for Windows and MAC, listing key functions in Spanish.

ES FUNCION BASICA table with columns for Windows and MAC, listing key functions in Spanish.

ES EMPAREJAMIENTO BLUETOOTH section with a diagram and instructions for pairing in Spanish.

ES ESPECIFICACIONES table listing model, keys amount, and other specifications in Spanish.

ES Hot-Swappable section with diagrams showing key replacement in Spanish.

FR FONCTION DE BASE table with columns for Windows and MAC, listing key functions in French.

FR FONCTION DE BASE table with columns for Windows and MAC, listing key functions in French.

FR APPAREJAGE BLUETOOTH section with a diagram and instructions for pairing in French.

FR SPECS table listing model, keys amount, and other specifications in French.

FR Hot-Swappable section with diagrams showing key replacement in French.

IT FUNZIONE DI BASE table with columns for Windows and MAC, listing key functions in Italian.

IT FUNZIONE DI BASE table with columns for Windows and MAC, listing key functions in Italian.

IT ACCOPPIAMENTO DEL BLUETOOTH section with a diagram and instructions for pairing in Italian.

IT SPECIFICHE table listing model, keys amount, and other specifications in Italian.

IT Hot-Swappable section with diagrams showing key replacement in Italian.

JP 基本機能 table with columns for Windows and MAC, listing key functions in Japanese.

JP 基本機能 table with columns for Windows and MAC, listing key functions in Japanese.

JP ペアリングブルートゥース section with a diagram and instructions for pairing in Japanese.

JP パラメーター table listing model, keys amount, and other specifications in Japanese.

JP Hot-Swappable section with diagrams showing key replacement in Japanese.

CN 基本功能 table with columns for Windows and MAC, listing key functions in Chinese.

CN 基本功能 table with columns for Windows and MAC, listing key functions in Chinese.

CN 配对蓝牙 section with a diagram and instructions for pairing in Chinese.

CN 参数 table listing model, keys amount, and other specifications in Chinese.

CN Hot-Swappable section with diagrams showing key replacement in Chinese.

MECHLANDS logo and various certification logos (CE, RoHS, etc.) at the bottom of the page.